



Davis Temperature & Humidity Sensor with Radiation Shield

Product Images



Short Description

Add a temperature/humidity sensor to your Vantage Pro2 system. Use with the Anemometer/Sensor Transmitter Kit for flexibility in siting options.

Description

Add a temperature/humidity sensor to your Vantage Pro2 system.

Use with the [Anemometer/Sensor Transmitter Kit](#) for flexibility in siting options.

Features both temperature and humidity sensors inside a passive radiation shield, which protects the sensors from solar radiation and other sources of radiated and reflected heat.

Perfect for installations where steep temperature gradients are uncommon and where sufficient wind keeps air moving through the passive radiation shield. If your installation does have steep temperature gradients or low wind, consider the Temperature/Humidity Sensor with 24-Hour Fan Aspirated Radiation Shield ([#6832](#)).

Additional Information

Brand	Davis Instruments
Measurements	Humidity, Temperature